



Data Collection and Preprocessing Phase

Date	10 th July 2024
Team ID	SWTID1719999219
Project Title	Crystal Clear Vision: Revolutionizing Cataract Prediction through Transfer Learning Mastery
Maximum Marks	6 Marks

Preprocessing Template

The images will be preprocessed by resizing, normalizing, augmenting, denoising, adjusting contrast, detecting edges, converting color space, cropping, batch normalizing, and whitening data. These steps will enhance data quality, promote model generalization, and improve convergence during neural network training, ensuring robust and efficient performance across various computer vision tasks.

Section	Description
Data Overview	<p>The retina dataset we chose for our project contains four categories: 1) normal 2) cataract 3) glaucoma 4) retina disease.</p> <p>However as only the first two categories were applicable to our project, some preprocessing steps were applied. The unnecessary categories were removed. Next, train, validation and test folders were created for normal and cataract.</p> <p>Totally there were 300 normal eye images and 100 cataract eye images. The split which was going to be used for train, validation and test was 80-10-10 respectively.</p>
Resizing	<p>Resize images to a specified target size.</p> <p>As we are using ResNet50, resizing to 224x224x3 would be applied.</p>
Normalization	<p>Normalize pixel values to a specific range.</p> <p>ResNet50 applies normalization after convolution layers.</p>

<p>Data Augmentation</p>	<p>Apply augmentation techniques such as flipping, rotation, shifting, zooming, or shearing.</p> <p>Ex: Image before augmenting:</p> <pre>image before augmenting (1632, 2464, 3)</pre>  <p>Image after augmenting:</p> 
<p>Denoising</p>	<p>Apply denoising filters to reduce noise in the images.</p> <p>N/A</p>
<p>Edge Detection</p>	<p>Apply edge detection algorithms to highlight prominent edges in the images.</p> <p>N/A</p>
<p>Color Space Conversion</p>	<p>Convert images from one color space to another.</p>

	N/A (Images are already in RGB format).
Image Cropping	<p>Crop images to focus on the regions containing objects of interest.</p> <p>N/A (Images in the dataset have already been cropped).</p>
Batch Normalization	<p>Apply batch normalization to the input of each layer in the neural network.</p> <p>ResNet50 applies batch normalization after convolution layers.</p>
Data Preprocessing Code Screenshots	
Loading Data	<p>Downloading from Kaggle:</p> <p>Downloading dataset from kaggle</p> <pre> \$ mkdir -p ~/.kaggle \$ cp kaggle.json ~/.kaggle \$ kaggle datasets download -d jr2ngb/cataractdataset Dataset URL: https://www.kaggle.com/datasets/jr2ngb/cataractdataset License(s): unknown Downloading cataractdataset.zip to /content 100% 3.34G/3.34G [03:21<00:00, 16.4MB/s] 100% 3.34G/3.34G [03:21<00:00, 17.8MB/s] \$ unzip '/content/cataractdataset.zip' </pre> <p>Remove unnecessary directories:</p>

	<pre>#to remove unnecessary datasets # Define the path to the folder containing the classes path = '/content/repository/yiweichen84-retina_dataset-914b0f4/dataset' # List all directories and store them in a Python list dirs = !ls -d \$path/*/ # Convert the paths to a list of strings dirs = [d.strip() for d in dirs] # Print the directories to be removed print(f"Directories to be removed: {dirs[-2]}, {dirs[-1]}") # Remove the last two directories !rm -r {dirs[-2]} !rm -r {dirs[-1]} # Verify the removal !ls \$path</pre> <p>Loading data from train and validation directories:</p> <pre>import tensorflow as tf train_dir='/content/repository/yiweichen84-retina_dataset-914b0f4/train' val_dir='/content/repository/yiweichen84-retina_dataset-914b0f4/validation' img_size=(224,224) train_data=tf.keras.preprocessing.image_dataset_from_directory(directory=train_dir, label_mode='binary', image_size=img_size, batch_size=32) val_data=tf.keras.preprocessing.image_dataset_from_directory(directory=val_dir, batch_size=32, label_mode='binary', image_size=img_size)</pre>
Resizing	<pre>import tensorflow as tf train_dir='/content/repository/yiweichen84-retina_dataset-914b0f4/train' val_dir='/content/repository/yiweichen84-retina_dataset-914b0f4/validation' img_size=(224,224) train_data=tf.keras.preprocessing.image_dataset_from_directory(directory=train_dir, label_mode='binary', image_size=img_size, batch_size=32) val_data=tf.keras.preprocessing.image_dataset_from_directory(directory=val_dir, batch_size=32, label_mode='binary', image_size=img_size)</pre>
Normalization	<p>Normalization is done after augmentation in this line:</p> <pre>augmented_img= tf.squeeze((augmented_img)/255.))[:, :, ::-1] #normalize after augmentati</pre>


	<pre> 1 conv1_bn 2 conv1_relu 3 conv1_bn 4 conv1_relu 5 pool1_pad 6 pool1_pool 7 conv2_block1_1_conv 8 conv2_block1_1_bn 9 conv2_block1_1_relu 10 conv2_block1_2_conv 11 conv2_block1_2_bn 12 conv2_block1_2_relu 13 conv2_block1_0_conv 14 conv2_block1_3_conv 15 conv2_block1_0_bn 16 conv2_block1_3_bn 17 conv2_block1_add 18 conv2_block1_out </pre> <p>The layers with suffix 'bn' in ResNet50 signify batch normalization.</p>
Data Augmentation	 <pre> } from tensorflow.keras import layers import tensorflow as tf # Now we are going to create a data augmentation layer to be used later with the model. data_augmentation = tf.keras.Sequential([layers.RandomFlip("horizontal"), layers.RandomRotation(0.2), layers.RandomZoom(0.2), layers.RandomHeight(0.2), layers.RandomWidth(0.2)], name="data_augmentation") # Now we will test this layer. path = "/content/repository/yiweiichen94-retina_dataset-914b6f4/dataset/2_cataract/cataract_075.png" img_show(path, "Image before augmenting") img = cv2.imread(path) augmented_img = data_augmentation(tf.expand_dims(img, axis=0)) augmented_img = tf.squeeze((augmented_img/255.0)[0, :, :, :]) # normalize after augmentation </pre>
Denoising	<p>Give the code snippet as an image (copy and paste the picture in this block).</p> <p>N/A</p>
Edge Detection	<p>Give the code snippet as an image (copy and paste the picture in this block).</p> <p>N/A</p>
Color Space Conversion	<p>Give the code snippet as an image (copy and paste the picture in this block).</p> <p>N/A</p>

Image Cropping	<p>Give the code snippet as an image (copy and paste the picture in this block).</p> <p>N/A</p>
Batch Normalization	<p>Give the code snippet as an image (copy and paste the picture in this block).</p> <pre> 1 conv1_bn 2 conv1_relu 3 pool1_pad 4 pool1_pool 5 conv2_block1_1_conv 6 conv2_block1_1_bn 7 conv2_block1_1_relu 8 conv2_block1_2_conv 9 conv2_block1_2_bn 10 conv2_block1_2_relu 11 conv2_block1_0_conv 12 conv2_block1_3_conv 13 conv2_block1_0_bn 14 conv2_block1_3_bn 15 conv2_block1_add 16 conv2_block1_out </pre> <p>The layers with suffix 'bn' in ResNet50 signify batch</p>